



NOTES:

1. PROVIDE MINIMUM OF 4' CLEARANCE ABOVE AND TO THE SIDE OF THE METER AND BACK FLOW PREVENTER AND AT LEAST 16 SQUARE FEET OF WORKING AREA.
2. METER, CONNECTIONS, AND REMOTE READ WIRE TO BE PURCHASED BY CUSTOMER THROUGH THE DISTRICT. ALL OTHER MATERIALS TO BE SUPPLIED BY CUSTOMER.
3. METER WILL BE READ ELECTRONICALLY FROM OUTSIDE OF BUILDING. CONTACT THE DISTRICT IF PRE-WIRING IS REQUIRED.
4. CUSTOMER IS RESPONSIBLE FOR THE MAINTENANCE AND INSTALLATION OF THE VALVES AND BACK FLOW PREVENTER. MANUFACTURER'S INSTALLATION INSTRUCTIONS MUST BE FOLLOWED.
5. BRANCHES ARE NOT ALLOWED UPSTREAM OF THE METER OR BACK FLOW PREVENTER.
6. METER TO BE INSTALLED IN A WARM, DRY, ACCESSIBLE AREA.
7. THE DISTRICT WILL DETERMINE THE TYPE OF BACK FLOW PREVENTER REQUIRED.
8. METERS SHALL NOT BE INSTALLED IN CRAWL SPACES.
9. METERS SHALL BE INSTALLED HORIZONTALLY.

REVISED 3/17/2015

METER CONFIGURATION

NTS



BRUNSWICK & TOPSHAM
WATER DISTRICT

PO BOX 489
TOPSHAM, MAINE 04086